Subject: RS-232 protocols on PC? - (nf)

Posted by Anonymous on Mon, 20 May 2013 03:32:02 GMT

View Forum Message <> Reply to Message

Originally posted by: mbr&#64fortune.UUCP

Message-ID:

Date: Thu, 19-Apr-84 15:06:36 EST

Article-I.D.: fortune.3106

Posted: Thu Apr 19 15:06:36 1984

Date-Received: Fri, 20-Apr-84 02:16:10 EST

Sender: notes@fortune.UUCP

Organization: Fortune Systems, Redwood City, CA

Lines: 21

I am writing code to do I/O using an RS-232 port on the IBM PC, and I need to support the following forms of handshaking:

software: DC1/DC3

ETX/ACK

hardware: DSR/DTR

CTS/RTS

I have read the section entitled "IBM Asynchronous Communications Adapter" (pp. 1-183 to 1-212) of the IBM PC/XT Technical Reference. I can find no information on how to set up handshaking. Do I have to code the protocol myself, or have I missed something in the documentation?

Please reply by mail. I will summarize to the net when the responses dwindle.

{ihnp4,ucbvax!amd70,hpda,sri-unix,harpo}!fortune!mbr

Subject: Re: RS-232 protocols on PC? - (nf)

Posted by jph on Mon, 20 May 2013 03:32:03 GMT

View Forum Message <> Reply to Message

Message-ID:

Date: Fri, 20-Apr-84 08:51:28 EST

Article-I.D.: whuxle.314

Posted: Fri Apr 20 08:51:28 1984

Date-Received: Sat, 21-Apr-84 01:17:41 EST

Sender: jph@whuxle.UUCP

Organization: Bell Labs, Whippany

Lines: 9

#R:fortune:14700012:whuxle:22700024:000:241

whuxle!jph Apr 20 08:51:00 1984

you have to write a routine to implement the protocol that you desire. The async support device only provide an interface to put/get characters from the comm line, with the assumptions that the user is handling any protocol related actions.

Subject: Re: RS-232 protocols on PC? - (nf)

Posted by Anonymous on Mon, 20 May 2013 03:32:08 GMT

View Forum Message <> Reply to Message

Originally posted by: mbr&#64fortune.UUCP

Message-ID:

Date: Tue, 24-Apr-84 15:05:22 EST

Article-I.D.: fortune.3146

Posted: Tue Apr 24 15:05:22 1984

Date-Received: Thu, 26-Apr-84 01:30:01 EST

Sender: notes@fortune.UUCP

Organization: Fortune Systems, Redwood City, CA

Lines: 10

#R:fortune:14700012:fortune:14700013:000:299

fortune!mbr Apr 24 10:57:00 1984

This is in reference to my question about how to do handshaking on an RS-232 port on the IBM PC. I've received several responses, all saying essentially the same thing: you have to code the protocol yourself. Many thanks to all who responded.

{ihnp4,ucbvax!amd70,hpda,sri-unix,harpo}!fortune!mbr

Subject: Re: RS-232 protocols on PC?

## Posted by ron@brl-vgr.ARPA (Ron on Mon, 20 May 2013 03:32:09 GMT

View Forum Message <> Reply to Message

Message-ID:

Date: Wed, 25-Apr-84 12:28:27 EST

Article-I.D.: brl-vgr.874

Posted: Wed Apr 25 12:28:27 1984

Date-Received: Fri, 27-Apr-84 00:15:43 EST

References:

Organization: Ballistics Research Lab

Lines: 7

Did you ever notice that in the PC glossary (obviously condensed from some larger IBM dictionarry) that the following definitions appear:

DSR: Data Set Ready

DTR: Distribution Tape Reel

-Ron